

POWERFLEX®

PART NUMBER

PFF60-902G

DESCRIPTION

CLIO MK4 Front Wishbone Rear Bush Caster Offset

INSTALLATION GUIDE

Contents (parts per pack):

- 2 x Polyurethane Bushes
- 2 x Stainless Steel Sleeves
- 2 x Aluminium Shells
- 2 x Powerflex Grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove the original bush from the arm, remembering to clean away any dirt and corrosion.
2. File away any sharp edges using a rounded file.
3. Insert the Aluminium Shells
4. Apply some of the supplied grease to the bore of the Shells, and insert the Polyurethane Bushes ensuring they are flush to the Aluminium Shells.
5. Apply some of the supplied grease to the bore of the bushes, and insert the Stainless Steel Sleeves into the bores of the bushes until they sit flush.
6. Refit the arm to the subframe, remembering to tighten all hardware to manufacturers recommended torque settings.



Figure 1 - Right Wheel configuration as viewed from front of car

